

# Contents

---

Introduction	xvii	
About the Author	xix	
<b>Chapter 1</b>	<b>Radiant Heating</b>	<b>1</b>
	Types of Radiant Panel Heating Systems	2
	Floor Panel Systems	2
	Ceiling Panel Systems	2
	Wall Panel Systems	5
	Hydronic Radiant Floor Heating	6
	System Components	6
	Designing a Hydronic Radiant Floor Heating System	28
	Coils and Coil Patterns	41
	Installing a Hydronic Radiant Floor Heating System (PEX Tubing)	44
	Servicing and Maintaining Hydronic Radiant Floor Heating Systems	49
	Troubleshooting Hydronic Floor Radiant Heating Systems	49
	Hydronic Radiant Heating Snow- and Ice-Melting Systems	51
	Electric Radiant Floor Heating	52
	Installing Electric Heating Mats or Rolls	58
	Installing Electric Cable	65
	Servicing and Maintaining an Electric Radiant Floor Heating System	67
	Troubleshooting Electric Radiant Floor Heating Systems	67
	Cooling for Hydronic Radiant Floor Systems	68

<b>Chapter 2</b>	<b>Radiators, Convectors, and Unit Heaters</b>	<b>71</b>
	Radiators	72
	Radiator Efficiency	74
	Radiator Heat Output	77
	Sizing Radiators	78
	Installing Radiators	79
	Radiator Valves	86
	Radiator Piping Connections	92
	Vents and Venting	93
	Steam Traps	99
	Troubleshooting Radiators	99
	Convectors	100
	Convector Piping Connections	101
	Hydronic Fan Convectors	106
	Troubleshooting Hydronic Fan Convectors	106
	Steam and Hot-Water Baseboard Heaters	107
	Construction Details	108
	Integral Fin-and-Tube Baseboard Heaters	112
	Installing Baseboard Units	113
	Baseboard Heater Maintenance	119
	Electric Baseboard Heaters	119
	Installing Electric Baseboard Heaters	124
	Kickspace Heaters	127
	Floor and Window Recessed Heaters	129
	Unit Heaters	130
	Unit Heater Piping Connections	135
	Unit Heater Controls	138
	Gas-Fired Unit Heaters	140
	Oil-Fired Unit Heaters	141
<b>Chapter 3</b>	<b>Fireplaces, Stoves, and Chimneys</b>	<b>145</b>
	Fireplaces	145
	Fireplace Location	145
	Fireplace Dimensions	146

	Fireplace Construction Details	149
	Firebox, Lintel, and Mantel	150
	Fireplace Hearth	151
	Ash Dump, Ashpit, and Cleanout Door	152
	Smoke Chamber	152
	Fireplace Dampers	153
	Modified Fireplaces	156
	Freestanding Fireplaces	157
	Rumford Fireplace	158
	Chimney Draft	162
	Chimney Construction Details	164
	Chimney Flues and Chimney Liners	165
	Smoke Pipe	167
	Cleanout Trap	168
	Chimney Downdraft	168
	Prefabricated Metal Chimneys	169
	Troubleshooting Fireplaces and Chimneys	169
	Stoves, Ranges, and Heaters	169
	Installation Instructions	177
	Operating Instructions	178
<b>Chapter 4</b>	<b>Water Heaters</b>	<b>179</b>
	Types of Water Heaters	179
	Direct-Fired Water Heaters	180
	Automatic Storage Water Heaters	180
	Multicoil Water Heaters	182
	Multiflue Water Heaters	183
	Instantaneous Water Heaters	184
	Indirect Water Heaters	185
	Quick-Recovery Heaters	189
	Slow-Recovery Heaters	189
	Heat Pump Water Heaters	190
	Combination Water Heaters	191
	Water Heater Construction Details	192
	Water Storage Tanks	193

	Tank Fittings	194
	Dip Tubes	194
	Anodes	197
	Valves	197
	Safety Relief Valves	197
	Vacuum Relief Valve	206
	Gas-Fired Water Heaters	209
	Storage Capacity	209
	Gas Burners	210
	Automatic Controls on Gas-Fired Water Heaters	210
	Combination Gas Valve	221
	Installation and Operation of Gas-Fired Water Heaters	225
	Hot-Water Circulating Methods	230
	Building and Safety Code Requirements	230
	Lighting and Operating Instructions	231
	Installation and Maintenance Checklist	232
	Troubleshooting Gas-Fired Water Heaters	233
	Oil-Fired Water Heaters	238
	Electric Water Heaters	240
	Troubleshooting Electric Water Heaters	242
	Manual Water Heaters	245
	Assembly and Installation of Manual Water Heaters	246
	Solar Water Heaters	246
<b>Chapter 5</b>	<b>Heating Swimming Pools</b>	<b>249</b>
	Classifying Pool Heaters	251
	Gas-Fired Pool Heaters	255
	Oil-Fired Pool Heaters	259
	Electric Pool Heaters	260
	Heat-Exchanger Pool Heaters	263
	Solar Pool Heaters	264

	Heat Pump Pool Heaters	267
	Sizing Pool Heaters	267
	The Surface-Area Method	270
	The Time-Rise Method	271
	Sizing Indoor Pool Heaters	271
	Installing Pool Heaters	271
	Pool Heater Repair and Maintenance	273
	Troubleshooting Pool Heaters and Equipment	274
<b>Chapter 6</b>	<b>Ventilation Principles</b>	<b>281</b>
	The Motive Force	282
	Inductive Action of the Wind	282
	Induced Draft	285
	Combined Force of Wind Effect and Thermal Effect	285
	Mechanical Ventilation	287
	Air Ventilation Requirements	287
	Roof Ventilators	289
	Types of Roof Ventilators	289
	Stationary-Head Ventilators	290
	Revolving Ventilators	290
	Turbine Ventilators	291
	Ridge Ventilators	293
	Siphonage Ventilators	294
	Fan Ventilators	294
	Components of a Roof Ventilator	295
	Motive Force to Cause Air Circulation	296
	Capacity of Ventilators	296
	Design and Placement of Inlet Air Openings	298
	Fresh Air Requirements	299
	Ventilator Bases	299
	Angle Rings	302
	Stiffener Angles	303
	Prefabricated Roof Curbs	303
	Ventilator Dampers	304

	Louver Dampers	305
	Sliding Sleeve Dampers	306
	Sliding Cone Dampers	306
	Butterfly Dampers	306
	Method of Calculating Number and Size of Ventilators Required	307
	Ventilator Calculation Examples	308
	Air Leakage	309
	Garage Ventilation	310
	Ventilation of Kitchens	311
	General Ventilation Rules	312
<b>Chapter 7</b>	<b>Ventilation and Exhaust Fans</b>	<b>315</b>
	Codes and Standards	315
	Definitions	315
	Types of Fans	317
	Furnace Blowers	319
	Basic Fan Laws	319
	Series and Parallel Fan Operation	321
	Fan Performance Curves	322
	General Ventilation	322
	Determining CFM by the Air-Change Method	323
	Determining CFM by the Heat Removal Method	325
	Determining Air Intake	326
	Screen Efficiency	326
	Static Pressure	327
	Local Ventilation	328
	Exhaust-Hood Design	
	Recommendations	332
	Fan Motors	333
	Troubleshooting Fans	337
	Fan Selection	341
	Fan Installation	344
	Fan Installation Checklist	344
	Air Volume Control	347

	Noise Control	347
	Fan Applications	347
	Attic Ventilating Fans	348
	Exhaust Fans	355
	Kitchen Exhaust Fans	355
	Bathroom Exhaust Fans	356
	Whole-House Ventilation	356
<b>Chapter 8</b>	<b>Air-Conditioning</b>	<b>361</b>
	Properties of Air	362
	Humidity	362
	Temperature	365
	Pressure	368
	Compression and Cooling	370
	Measuring the Physical Properties of Air	372
	Cleaning and Filtering the Air	374
	Standards of Comfort	376
	The Comfort Chart	377
	Cooling Load Estimate Form	379
	Indoor-Outdoor Design Conditions	383
	Ventilation Requirements	384
	Cooling a Structure	386
	External Sources of Heat	386
	Internal Sources of Heat	392
	Calculating Infiltration and Ventilation Heat Gain	394
	Rule-of-Thumb Methods for Sizing Air Conditioners	394
	HVAC Contractor's Cooling Load Estimate	395
	Using the ACCA Design Manuals for Sizing Air-Conditioning Systems	396
	Central Air-Conditioning	397
	Cooling Methods	397
	Central Air-Conditioning Applications	410
	Room Air Conditioners	421

<b>Chapter 9</b>	<b>Air-Conditioning Equipment</b>	<b>423</b>
	Mechanical Refrigeration Equipment	423
	Compressors	424
	Troubleshooting Compressors	430
	Compressor Replacement	435
	Electric Motors	435
	Troubleshooting Electrical Motors	436
	Gas Engines	437
	Electrical Components	437
	Troubleshooting Electrical Components	438
	Condenser	439
	Condenser Service and Maintenance	442
	Troubleshooting Condensers	443
	Receiver	443
	Evaporator	447
	Evaporator Service and Maintenance	447
	Troubleshooting Evaporators	447
	Refrigerants	448
	Liquid Refrigerant Control Devices	449
	Automatic Expansion Valves	449
	Thermostatic Expansion Valves	450
	Float Valves	453
	Capillary Tubes	454
	Refrigerant Piping	454
	Refrigerant Piping Service and Maintenance	455
	Troubleshooting Refrigerant Piping	456
	Filters and Dryers	457
	Pressure-Limiting Controls	457
	Water-Regulating Valves	458
	Automatic Controls	459
	System Troubleshooting	459
	General Servicing and Maintenance	460
	Regular Maintenance	463
	Pumping Down	464
	Purging	464
	Evacuating the System	464

	Charging	465
	Silver-Brazing Repairs	467
<b>Chapter 10</b>	<b>Heat Pumps</b>	<b>471</b>
	Heat Pump Operating Principles	471
	Heating Cycle	471
	Cooling Cycle	473
	Defrost Cycle	473
	Types of Heat Pumps	476
	Air-Source Heat Pumps	476
	Ground-Source Heat Pumps	481
	Water-Source Heat Pumps	483
	Other Types of Heat Pumps	485
	Gas-Fired Heat Pumps	485
	Dual-Fuel Heat Pump System	486
	Dual-Source Heat Pumps	486
	Ductless Heat Pumps	487
	Heat Pump Performance and Efficiency	
	Ratings	487
	Seasonal Energy Efficiency Ratio (SEER)	488
	Heating Season Performance Factor (HSPF)	488
	Coefficient of Performance (COP)	488
	Energy Efficiency Rating (EER)	488
	Energy Star Rating	488
	Heat Pump System Components	488
	Compressor	490
	Indoor Coil and Blower	491
	Outdoor Coil and Fan	491
	Refrigerant Lines	491
	Reversing Valve and Solenoid	491
	Thermostatic Expansion Valve	493
	Desuperheater	494
	Control Box	494
	Fan/Blower Motors	499
	Heat Pump Defrost System	499
	High-Pressure Switch	500
	Low-Pressure Switch	501

Other Electric/Electronic Heat Pump		
Controls and Connections	501	
Accumulator	501	
Room Thermostat	501	
Service Valves and Gauge Ports	502	
Gauge Manifold	503	
Filter Dryer	503	
Crankcase Heater	503	
Muffler	505	
Sizing Heat Pumps	505	
Heat Pump Installation		
Recommendations	507	
Heat Pump Operating Instructions	510	
Heating	510	
Cooling	511	
Heat Pump Service and Maintenance	511	
Service and Maintenance Checklist	512	
Adjusting Heat Pump Refrigerant Charge	513	
Troubleshooting Heat Pumps	514	
Troubleshooting Heat Pump		
Compressors	517	
<b>Chapter 11</b>	<b>Humidifiers and Dehumidifiers</b>	<b>519</b>
	Humidifiers	521
	Spray Humidifiers	522
	Pan Humidifiers	523
	Stationary-Pad Humidifiers	524
	Steam Humidifiers	524
	Bypass Humidifiers	525
	Power Humidifiers	526
	Automatic Controls	526
	Installation Instructions	529
	Service and Maintenance Suggestions	534
	Troubleshooting Humidifiers	535
	Dehumidifiers	537
	Absorption Dehumidifiers	538
	Spray Dehumidifiers	541

	Refrigeration Dehumidifiers	541
	Automatic Controls	542
	Installation Suggestions	542
	Operating and Maintenance Suggestions	542
	Troubleshooting Dehumidifiers	543
<b>Chapter 12</b>	<b>Air Cleaners and Filters</b>	<b>547</b>
	Electronic Air Cleaners	547
	Charged-Media Air Cleaners	549
	Two-Stage Air Cleaners	553
	Automatic Controls	554
	Clogged-Filter Indicator	556
	Performance Lights	557
	Sail Switch	559
	In-Place Water-Wash Controls	561
	Cabinet-Model Control Panels	563
	Installation Instructions	564
	Electrical Wiring	564
	Maintenance Instructions	565
	Replacing Tungsten Ionizing Wires	568
	Troubleshooting Electronic Air Cleaners	569
	Air Washers	571
	Air Filters	572
	Dry Air Filters	574
	Viscous Air Filters	574
	Filter Installation and Maintenance	575
<b>Appendix A</b>	<b>Professional and Trade Associations</b>	<b>577</b>
<b>Appendix B</b>	<b>Manufacturers</b>	<b>589</b>
<b>Appendix C</b>	<b>HVAC/R Education, Training, Certification, and Licensing</b>	<b>601</b>
<b>Appendix D</b>	<b>Data Tables</b>	<b>605</b>
<b>Appendix E</b>	<b>Psychrometric Charts</b>	<b>643</b>
<b>Index</b>		<b>647</b>

